



COLLAPSIBLE COLUMN CARTS



PLATE MATE has 3 types of collapsible column carts;

Available models:

PM 48 collapsible: with holding capacity of 48 plates

PM 60 collapsible: with holding capacity of 60 plates

PM 84 collapsible: with holding capacity of 84 plates




These PLATE MATE models have been specifically designed for rentals, catering companies and companies that are located in small quarters. These models can be folded after use and hung on a wall or put in a corner for storage; therefore you can save space twice with this model, first when in use with plates and then when not in use.

All models are made of stainless steel tubes and require no maintenance. Cleaning can be done with a high-pressure cleaner or with a soap solution and a brush. A protective cover is available as an optional item to protect against odors and prevent the dish contents from drying out.

*Save space
twice!*

www.plate-mate.com



The Product Group, Inc.
Canton, Ohio

1-800-860-6283
www.plate-mate.com



COLLAPSIBLE COLUMN CARTS

ASSEMBLY

1. Remove the column and the frame from the box. Place the column in the foot of the frame, where the foot has already been put in place.
2. Slide the pin C1, which is already in place, upwards until the column fits under it and then slide the pin into the column head.
3. The unit can be collapsed by lifting the INNER FRAME, which is somewhat shorter than the OUTER FRAME, out of the fastening block. This is most easily done by placing your hands in the center of the cross bracing at the top and pulling the two frames toward each other, while using your foot to push the inner frame upwards. At first this will be somewhat difficult to do because all the parts of the unit are still new.

